

When disassembled the standard Ping-Pong can not be re-assembled. This manual mainly refers to when the product is to be recycled.

This manual does not apply to the Ping-Pong knockdown version, that version have a separate instruction manual.

No special tools are needed for separation and disassembly, each component is separated by hand.





The footrest in stainless steel is easily separated by turning the couplings in each side manually in a counter-clockwise direction. No need for special tools. The wooden Ping-Pong parts (Wooden table top, Wooden table top beam, 2 x Wooden table sides) are glued together. Apply force to separate.



Ping-Pong Components:

- Wooden table top
- Wooden table top beam
- 2 x Wooden table sides
- Steel footrest
- 2 x Steel footrest couplings

