BOB Light assembly

BLÅ STATION

Single BOB Light D840 / D841



Important: It is mandatory that any connection to the main electricity supply shall be made by a qualified electrician!

Blå Station AB | Box 100, 2096 22 Åhus, Sweden | Tel: +46 44 249070 | Fax: +46 44 241214
E-mail: info@blastation.se | www.blastation.se

BOB Light assembly

Parts included in Single BOB Light package D840 / D841

Optional Extension cord 1,5m Wieland/EU socket included if ordered

Blå Station AB | Box 100, 2096 22 Åhus, Sweden | Tel: +46 44 249070 | Fax: +46 44 241214
E-mail: info@blastation.se | www.blastation.se

BOB Light assembly

It is preferable to be at least two persons helping with the assembly. Start by loosening cable tensioner at the lower end of the BOB Light frame with a phillips screwdriver.

Blå Station AB | Box 100, 2096 22 Åhus, Sweden | Tel: +46 44 249070 | Fax: +46 44 241214
E-mail: info@blastation.se | www.blastation.se

BOB Light assembly

BLÅ STATION

Attach the lamp head to the electrical cord by pressing the male and female fittings into place. Notice that the male and female fits only when aligned to match. There should be a ”Click” sound when connected correctly.

Blå Station AB | Box 100, 2096 22 Åhus, Sweden | Tel: +46 44 249070 | Fax: +46 44 241214
E-mail: info@blastation.se | www.blastation.se

BOB Light assembly

Attach the lamp head to the lamp frame. First adjust the cord from the cord tensioner at the bottom of the lamp frame. Then at the top there is a notch in the threading and a matching notch in the lamp head. Align the notch and the treading and tighten the thread as much as possible.



Blå Station AB | Box 100, 2096 22 Åhus, Sweden | Tel: +46 44 249070 | Fax: +46 44 241214
E-mail: info@blastation.se | www.blastation.se

BOB Light assembly

Tighten the cord tensioner at the bottom of the lamp frame.

Next step is to attach the BOB Lamp to the BOB Module.
Place the BOB Module so that the plastic female fittings in facing you. Align the Bob Light to The BOB Module so that the bottom 2 holes of the BOB Light align with the pre-made holes of the BOB module. The top fitting of the BOB Light should align with the plastic female fitting of the BOB Module like the picture below.

Blå Station AB | Box 100, 2096 22 Åhus, Sweden | Tel: +46 44 249070 | Fax: +46 44 241214
E-mail: info@blastation.se | www.blastation.se

BOB Light assembly

Bring the 3 screws and 3 metal washers that is included in the BOB Light package and a phillips screwdriver. Place the metal washers between the BOB Light and BOB Module and screw the 3 screws to place.

Blå Station AB | Box 100, 2096 22 Åhus, Sweden | Tel: +46 44 249070 | Fax: +46 44 241214
E-mail: info@blastation.se | www.blastation.se

BOB Light assembly

BLÅ STATION

Correctly assembled and attached BOB Light to the BOB module to the left. Just continue to build the BOB Sofa with the next module as normal (metal male to plastic female fitting) with the BOB Lamp attached as seen to the right.



BOB Sofa main assembly guide can be found here - www.blastation.com/bob-instructions

Blå Station AB | Box 100, 2096 22 Åhus, Sweden | Tel: +46 44 249070 | Fax: +46 44 241214
E-mail: info@blastation.se | www.blastation.se